

Introduction

Before beginning the shunt switch pod installation, ensure that all programs are closed on the Allegro QX.

1 Remove Allegro Terminal Guard

- 1 Remove screws from the gray terminal guard.



- 2 Remove guard from the Allegro QX.

2 Install Shunt Pod

- 1 Press pod over terminals (as shown) until completely in place.



- 2 Secure with included screws.

3 Enable Shunt Pod Configuration

- 1 On the Allegro QX, open the **ShuntpodConfig** application.
- 2 Tap the **Shunt pod is attached** check box, and then the **OK** button.

